

COPS Guide - Data Transfer (Windows)

contributors: [shaun@](#)

updated: 05-AUG-2024

Backup

- Restart Windows
 - Force Restart Windows (`shutdown -r -f -t 00`) now to provide a clean slate for proceeding
- [OPTIONAL] Create a new System Restore point
- Disable Antivirus
 - (Some of our extraction tools prompt false positives in most security packages)
- Create a Job# number folder on a Transfer Drive
 - Create a new folder with the current job number (ie. 'Job#5000') to save User Data to
- User Profile
 - use Forensit Transwiz, Fast Pack (no compression), use default filename, no password
- Web Browsers
 - For each web browser installed export the following:
 - Export Bookmarks (ie. 'Web Browser - Google Chrome - Bookmarks - 2024-07-15.html')
 - Google Chrome URL: `chrome://bookmarks`
 - Microsoft Edge URL: `edge://favorites`
 - Mozilla Firefox Hotkey: `Ctrl+Shift+0`
 - Microsoft Internet Explorer: Copy Favorites folder (%USERPROFILE%\Favorites)
 - Export Passwords (ie. 'Web Browser - Google Chrome - Passwords - 2024-07-15.csv')
 - Google Chrome URL: `chrome://password-manager/passwords` or `chrome://settings/passwords` (older versions)
 - Microsoft Edge URL: `edge://wallet/passwords` or `edge://settings/passwords` (older versions)
 - Mozilla Firefox URL: `about:Logins`
 - Microsoft Internet Explorer: Use [Nirsoft IE PassView](#)
- Installed Programs (ie. 'Installed Programs - 2024-07-15.html')
 - use Nirsoft UninstallView, save all as Horizontal HTML
- License Keys (ie. 'License Keys - 2024-07-15.html')
 - use Nirsoft ProduKey and Nirsoft Product Key Scanner
- Emails
 - Extract Passwords and Server Settings
 - Nirsoft Mail PassView
 - Nirsoft WinMailPassRec
 - Nirsoft PstPassword
 - Backup any accounts set up as POP
 - [How to export emails to file in Outlook](#)
- Check C: Drive for unusual files/folders
 - copy to Job folder copying the C: Drive file structure (TransferDrive:\Job#5000\C\FolderToSave)
- [OPTIONAL] Create Winget Install Script
 - <https://winstall.app/> - Select Desired Programs - Generate Script - Download both Batch (.bat) and PowerShell (.ps1) scripts
- Drivers ('TransferDrive:\Job#5000\Drivers - 2024-07-24')
 - Open PowerShell as Administrator and run (update with your export folder location):
`Export-WindowsDriver -Online -Destination REPLACE-WITH-EXPORT-FOLDER`
- Enable Antivirus

Prepare New Device (if required)

- Bypass Network Registration in Windows 11 Out of Box Experience
 - Shift+F10 to open Command Prompt:
 - Enter the command: OOBE\BYPASSNRO
 - Select 'I don't have an internet connection'
 - Select 'Continue with limited setup' (to create)
 - Create a Local Account named 'COPS' (no password)
- Configure System Restore
- Create a new System Restore point 'COPS - Fresh Windows 11 Install'
- Connect to the Internet after Windows logs into the COPS user account
- Configure Time/Date
- Configure Windows Update
- Update Apps via Microsoft Store
- Update Apps via Winget
- Update Windows
- Update Office apps
- Check for Device Manager for bangs(!)
 - Check for missing or faulty drivers, and install/update as required (SDIO)
- [OPTIONAL] Update remaining Drivers (SDIO)
- [If you installed/updated any drivers:] Verify Drivers (verifier)
 - Turn On Windows Verifier:
 - Run Win+R : verifier
 - Select Create standard settings
 - Click Next
 - Select Automatically select all drivers on this computer
 - Click Finish
 - Restart Windows (shutdown -r -f -t 00)
 - Windows Verifier works by stressing out drivers as they're loaded (it is expected that the computer's performance will be impacted while verifier is enabled)
 - If Windows loads into the desktop OK and does not crash with verifier enabled, then all is good and you can proceed to turn it off
 - Turn Off Windows Verifier:
 - Run Win+R : verifier
 - Select Delete existing settings
 - Click Finish
 - Restart Windows (shutdown -r -f -t 00)

Restore

- Install Programs
 - you can use the winget install script for this if you made one
 - > install programs before restoring the user profile, as otherwise some required registry entries may not exist yet
- Restore User Profile using Transwiz
 - make Administrator, make default user, set no password and set password does NOT expire
- Copy over any C: Drive files/folders that were backed up
- Restart Windows (this should log in to the restored user profile)
 - open a command prompt window (or similar) as Administrator to ensure account has admin priviledges
- Install Printer Drivers

If you can not install the printer drivers + software without the printer present, save the printer package installer to C:\COPS\ and create a shortcut to it on the customer's desktop

- Check Web Browsers and restore Bookmarks and Passwords from backups as required
- Activate software using extracted keys or accounts as required
- Configure email accounts as required
- Install additional drivers as required
- Move any USB Dongles from the old device (Wireless mice, wifi, blue adapters, etc...)
- Update Apps via Microsoft Store
- Update Windows
- Update Office apps if present
- Restart Windows
- Remove 'COPS' user account
 - Run: netplwiz - Select COPS - Click Remove
 - Delete C:\Users\COPS\ folder
 - Empty Recycle Bin
- Windows Maintenance (run the following commands as Admin)

```
winget source update
winget upgrade --all --silent
sfc /scannow
dism /online /cleanup-image /startcomponentcleanup /resetbase
dism /online /cleanup-image /restorehealth
sfc /scannow
```
- Restart Windows
- Create a new System Restore point 'COPS - Completed Data Transfer'