COPS Guide - System Service (Windows)

contributors: shaun@

updated: 11-JUL-2024

Software

- Restart Windows
- Configure System Restore (7%)
- Create a new System Restore point "COPS Pre System Service"
- Task Manager
 - o Disable unwanted startup items
- Wintoys
 - Install Wintoys

```
winget install wintoys or
winget install 9P8LTPGCBZXD or
ms-windows-store://pdp/?ProductId=9P8LTPGCBZXD
```

- o Performance Tab
 - Ultimate performance power plan | Turn ON if Desktop / Turn OFF if Laptop
 - HAGS (hardware-accelerated GPU scheduling) | Turn ON
 - VBS (virtualization-base security) | Turn ON
 - Disable unwanted startup items

- Update software
 - o Windows Update

old Windows 10 builds can use the Windows 10 Update Assistant to jump to the latest build

- o Update Apps via Winget
- o Update Apps via Microsoft Store
- Update Office Apps
- Update Drivers
- Maintenance

o r

Hardware

- Check all buttons and ports are free from debris and working functioning correctly
- Air compress out system as required
- Wipe down device and clean surfaces